

HYTORC

The World's Most Trusted Industrial Bolting Systems



MXT+™ Hydraulic Torque Wrench **Basic Operations Manual**

333 Route 17 N.
Mahwah, NJ 07430
USA

800-FOR-HYTORC
(800-367-4986)
201-512-9500

hytorc.com



ABOUT THIS DOCUMENT

ORIGINAL INSTRUCTIONS

This manual provides information for the MXT+™ Hydraulic Torque Wrench models MXTP-01, MXTP-03, MXTP-05, MXTP-10

Notice. The information contained in this document is subject to change without notice. Visit HYTORC.com for the most current version of this user manual. HYTORC Division UNEX Corporation ("HYTORC") makes no warranty of any kind regarding this material, including but not limited to implied warranties of merchantability and fitness for a particular purpose. HYTORC shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. It is recommended that the end-user or repair technician insure they have obtained and are familiar with the latest version of the manual for the equipment outlined in this document.

Restricted Rights Legend. Use and duplication of the information contained within this manual is limited to the purchaser, end user, or licensed HYTORC representative. It is recommended that proper training for the equipment outlined in this manual be conducted by a HYTORC-authorized training representative for any person who is operating or repairing the equipment outlined in this document. Modification of, or disclosure by any other agency or representative is strictly forbidden.

Product Modifications. HYTORC does not allow any product in this manual to be modified by any end user, without exception. Should an application require modification to a product please consult your local HYTORC representative.

NOTICE OF PROPRIETARY RIGHTS: HYTORC is the owner of all content included in this document and all right, title and interest to such content shall remain with HYTORC.

COPYRIGHT NOTICE: © 2024 HYTORC. Any unauthorized use or distribution of any material from this document without written permission is strictly prohibited.

TRADEMARK NOTICE: MXT® and MXT+™ are trademarks of HYTORC. This document contains numerous registered, unregistered and/or pending trademarks and service marks of HYTORC in the U.S. and other countries.

PATENT NOTICE: Products in this document are covered by issued and/or pending patents in the U.S. and other countries.

Warranty. The MXT+ Hydraulic Torque Tool has a two-year limited warranty. Every tool is tested before leaving the factory and is warranted to be free from defects in workmanship and materials. HYTORC will repair or replace, without charge, any tool which, upon examination, proves to be defective in workmanship or materials for two (2) years after the date of purchase. This warranty does not cover damage resulting from repairs made or attempted by unauthorized repair facilities or technicians. The repair and replacement remedies described herein are exclusive. In no event shall HYTORC be liable for any incidental, special, or consequential damages, including loss of profits. This warranty is exclusive and in lieu of all other warranties or conditions, written or oral, expressed or implied for merchantability or fitness for particular use or purpose. This warranty gives you specific legal rights. You may also have other rights that vary from state to state and province to province. In those states that do not allow the exclusion of implied warranties or limitation of incidental or consequential damages, the above limitations or exclusions may not apply to you. If you have questions about the warranty, contact our customer service center at 201-828-5270.

Printed in the USA. March 2024

NOTICE OF PROPRIETARY RIGHTS: HYTORC Division UNEX Corporation ("HYTORC") is the owner of all content included in this document and all right, title and interest to such content shall remain with HYTORC. **COPYRIGHT NOTICE:** © 2024 HYTORC. Any unauthorized use or distribution of any material from this document, without HYTORC's written permission, is strictly prohibited. **TRADEMARK NOTICE:** This document contains numerous registered trademarks and servicemarks of HYTORC in the U.S. and other countries. **PATENT NOTICE:** Products in this document are covered by numerous registered and/or pending patents in the U.S. and other countries.

TABLE OF CONTENTS

1. GENERAL SAFETY INFORMATION	1
2. TOOL DESCRIPTION	6
3. PREPARATION AND SETUP	8
4. BOLTING WITH SOCKET AND REACTION ARM	10
5. BOLTING WITH THE HYTORC WASHER	14
6. BOLTING WITH THE HYTORC NUT	15
7. CARE AND MAINTENANCE	16
CHANGELOG	17

1. GENERAL SAFETY INFORMATION



WARNING! Read all safety warnings designated by the  symbol and all instructions.
WARNING! Read all instructions before use. To reduce the risk of injury user must read manual.

Instructions in this section are compliant with ISO-11148-6:2012 and ISO-12100:2010.

A. GENERAL

- **Employer Responsibility:** The user's employer shall assess the specific risks that can be present as a result of each use.
- **Maintenance Instructions:** General maintenance recommendations include care and handling instructions (see Section 7).
- **Special Markings on the Tool:** There are no special markings or symbols on the tool.
- **Residual Risks:** When this tool is used for its intended purpose by trained individuals equipped with adequate personal protective equipment according to the instructions in this document, there are no known residual risks.
- **Statement of Use:** The MXT+ Hydraulic Torque Tool is intended for use in tightening fasteners with controlled torque in heavy duty industrial bolting applications.
- **Trained User Only:** This tool should be used only by fully trained personnel, and this document is written only for trained professionals. This tool should not be used without proper training and supervision. Contact HYTORC for additional training information.

B. GENERAL SAFETY RULES

- **Maintenance must be performed by a qualified HYTORC technician.**
- **Operating the tool in any fashion other than as described herein can result in serious bodily injury and is forbidden.**
- **For multiple hazards, read and understand the safety instructions before installing, operating, repairing, maintaining, changing accessories on, or working near the tool.** Failure to do so can result in serious bodily injury.
- **Only qualified and trained operators should install, adjust or use the tool.**
- **Do not modify this tool.** Modification of the tool invalidates the warranty and can reduce the effectiveness of safety measures and increase the risks to the operator.
- **Do not discard the safety instructions;** give them to the operator.
- **Do not use the tool if it has been damaged.**
- **Tools shall be inspected periodically to verify that the ratings and markings are legibly marked on the tool.** The employer/user shall contact the manufacturer to obtain replacement marking labels when necessary.

C. PROJECTILE HAZARD

- **Failure of the workpiece, of accessories or even of the inserted tool itself can generate high-velocity projectiles.**
- **Always wear impact-resistant eye protection during operation of the tool.** The grade of protection required should be assessed for each use.
- **Ensure that the workpiece is securely fixed.**

D. ENTANGLEMENT HAZARDS

- Entanglement hazards can result in choking, scalping and/or lacerations if loose clothing, personal jewelry, neckwear, hair or gloves are not kept away from the tool and accessories.
- Gloves can become entangled with the rotating drive, causing severed or broken fingers.
- Rotating drive sockets and drive extensions can easily entangle rubber-coated or metal-reinforced gloves.
- Do not wear loose-fitting gloves or gloves with cut or frayed fingers.
- Never hold the drive, socket or drive extension while operating tool.
- Keep hands away from rotating drives.

E. OPERATING HAZARDS

- The use of the tool can expose the operator's hands to hazards including crushing, impacts, cuts and abrasions and heat. Wear suitable gloves to protect hands.
- Operators and maintenance personnel must be physically able to handle the bulk, weight and power of the tool.
- Hold the tool correctly; be ready to counteract normal or sudden movements and have both hands available.
- Maintain a balanced body position and secure footing.
- In cases where the means to absorb the reaction torque are requested, it is recommended to use a suspension arm whenever possible. If that is not possible, side handles are recommended for straightcase and pistol-grip tools. Reaction bars are recommended for angle nutrunners. In any case, it is recommended to use a means to absorb the reaction torque above 4 N·m for straight tools, above 10 N·m for pistol-grip tools, and above 60 N·m for angle nutrunners.
- Release the start-and-stop device in case of an interruption of the energy supply.
- Use only lubricants recommended by the manufacturer.
- Beware of crushing hands between tool and workpiece, especially when unscrewing.

F. REPETITIVE MOTIONS HAZARDS

- When using tool the operator can experience discomfort in hands, arms, shoulders, neck, or other parts of the body.
- The operator should adopt a comfortable posture while maintaining secure footing and avoiding awkward or off balanced postures. The operator should change posture during extended tasks to help avoid discomfort and fatigue.
- If the operator experiences symptoms such as persistent or recurring discomfort, pain, throbbing, aching, tingling, numbness, burning sensations or stiffness, these warning signs should not be ignored. The operator should tell the employer and consult a qualified health professional.

G. ACCESSORY HAZARD

- Disconnect tool from the energy supply before changing the inserted tool or accessory.
- Do not touch sockets or reaction arms during use, as this can cause serious injury.
- Use only sizes and types of accessories that are recommended by the tool manufacturer.
- Use only impact grade sockets in good condition, as sockets in poor condition can shatter and become a projectile.

H. WORKPLACE HAZARDS

- **Slips, trips and falls are major causes of workplace injury.** Be aware of slippery surfaces caused by the use of the tool and also of trip hazards caused by the air line or hydraulic hose.
- **Proceed with care in unfamiliar surroundings.** Hidden hazards, such as electricity or other utility lines, can exist.
- **The tool is not intended for use in potentially explosive atmospheres and is not insulated against electric power.**
- **Make sure there are no electrical cables, gas pipes, etc., that can cause a hazard if damaged by use of the tool.**

I. DUST AND FUME HAZARDS

- **Where dust or fumes are present in the environment where this tool is used, follow instructions as required by the employer and occupational health and safety regulations to provide respiratory protection for tool users.**
- **Dust and fumes generated when using power tools can cause ill health (for example cancer, birth defects, asthma and/or dermatitis); risk assessment and implementation of appropriate controls for these hazards are essential.**

J. NOISE HAZARDS

- **Exposure to high noise levels can cause permanent, disabling hearing loss and other problems, such as tinnitus (ringing, buzzing, whistling or humming in the ears).** Therefore a risk assessment and implementation of appropriate controls for these hazards are essential.
- **Appropriate controls to reduce risk may include damping materials to prevent workpieces from “ringing”.**
- **Use hearing protection in accordance with instructions and as required by health and safety regulations.**
- **Operate and maintain the tool as recommended in instructions, to prevent increase in noise levels.**
- **If the tool has a silencer, always ensure it is in place and in good working order when operating.**
- **Select, maintain and replace tool as required to prevent an unnecessary increase in noise.**

K. VIBRATION HAZARDS

- **Exposure to vibration can cause disabling damage to the nerves and blood supply of the hands and arms.**
- **Keep hands away from the nutrunner sockets.**
- **If you experience numbness, tingling, pain or whitening of the skin in your fingers or hands, stop using the tool, tell your employer and consult a physician.**
- **Operate and maintain the tool as recommended, to prevent unnecessary increase in vibration levels.**
- **Do not use worn or ill-fitting sockets or extensions, as this is likely to cause a substantial increase in vibration.**
- **Select, maintain and replace tool as required to prevent an unnecessary increase in vibration levels.**
- **Sleeve fittings should be used where practicable.**
- **Hold the tool lightly but securely; the risk from vibration is generally greater with a tighter grip.**

L. ADDITIONAL SAFETY INSTRUCTIONS FOR HYDRAULIC POWER TOOLS

- **Do not exceed the maximum relief-valve setting stated on the tool.**
- **Carry out a daily check for damaged or worn hoses or hydraulic connections and replace if necessary.**
- **Use only clean oil and filling equipment.**
- **Power units require a free flow of air for cooling purposes and should, therefore, be positioned in a well-ventilated area free from hazardous fumes.**
- **Ensure that couplings are clean and correctly engaged before operation.**
- **Do not inspect or clean the tool while the hydraulic power source is connected.** Accidental engagement of the tool can cause serious injury.
- **Do not install or remove the tool while the hydraulic power source is connected.** Accidental engagement of the tool can cause serious injury.
- **Be sure all hose connections are tight.**
- **Wipe all couplers clean before connecting.** Failure to do so can result in damage to the quick couplers and cause overheating.

L.2. PUMP UNITS

- **Only use HYTORC pump units.** Do not modify the pump unit in any way.
- **Do not use electric pumps in potentially volatile atmospheres.** If in doubt, use a pneumatic pump unit. Metal-on-metal contact can cause sparks. Take appropriate additional measures.
- **Make sure that maximum operating pump pressure is under 10,000 PSI (700 bar).**
- **Make sure that the pump unit is properly grounded.**
- **Make sure pump is filled with HYTORC 32 AW hydraulic oil.** Check local conditions to be sure hydraulic oil has the correct ISO viscosity rating for your local climate. Do not mix different grades of oil.
- **Make sure that the oil level is between MIN and MAX indicator.** Use the oil level sight glasses to check level.
- **Make sure that the oil filler cap is secure.**

L.3. HYDRAULIC HOSES

- **Only use HYTORC hydraulic hoses.** Do not modify hoses in any way.
- **Make sure that all hoses are securely connected and are not kinked or twisted.**
- **Keep all hoses away from reaction points.**
- **Replace any damaged hoses immediately.** Replace all hoses at least every three years.

L.4. REACTION ARMS

- **Only use HYTORC reaction arms.** Do not modify reaction arms in any way.
- **Place reaction arm against a solid reaction point that can handle the load.**
- **Make sure that at least 0.5" (12 mm) of reaction arm contacts the reaction point.**
- **Make sure that the reaction arm is locked onto the spline of the tool.**
- **Do not place the reaction arm against a round or inclined reaction point.**
- **Do not place any part of your body between the reaction arm and the reaction point.**



L.5. SOCKETS

- Always use premium impact grade sockets.
- Always use the strongest socket for the job.
- Always react the wrench in-line with the nut.
- Always take special care with extensions and adapters.
- Always pin the socket to the drive.
- Never use a cut-down or modified socket.
- Never strike a socket under load.
- Always avoid the danger zones.
- Always inspect every socket before use.
- Always make sure the socket's width across flats (AF) matches that of the nut or bolt.
- **Do not use common extension pieces or step-up/step-down adapters.** HYTORC can develop customized accessories to ensure safe operation. Contact your local HYTORC representative for information.
- **Do not use chrome-plated sockets, sockets that have been excessively heated or cooled or sockets that are deformed or brittle from use.**


M. GENERAL OPERATOR GUIDELINES

- **Only qualified personnel who have thoroughly read this document may operate this tool.** Failure to safely operate this tool may result in serious injury or death.

N. PERSONAL PROTECTIVE EQUIPMENT (PPE)

- Always wear appropriate protective equipment including gloves, impact-resistant eye protection, hearing protection, hard hat and safety shoes when operating tool. Check local conditions for each use.


2. TOOL DESCRIPTION



The MXT+ Hydraulic Torque Wrench combines the best features from the original MXT tool with the latest advanced technology including coaxial reaction drive, auto-release feature and a new cycle counter.

- Constructed from higher strength materials for rugged industrial use and highly repeatable performance.
- The coaxial drive combined with rear reaction feature provide flexibility to configure the tool in the field, essentially replacing the need for two separate tools with one single tool.
- The MXT+ Wrench is compatible with standard sockets as well as the HYTORC Washer and HYTORC Nut for safe, simple and precise mechanical tensioning.
- An integrated auto-release feature and new quick-couplers provide faster job setup and completion.
- The new cycle counter helps keep the tool in calibration, allowing users to schedule preventative maintenance for peak performance and longer tool life.
- Dual Reaction: The tool accommodates both rear-attaching and concentric reaction fixtures.
- Reversible Square Drive: Allows rapid change between tighten and loosen modes.
- Uniswivel 180°/360° adjustable coupler provides maximal freedom in arranging tools and hoses.
- Concentric Reaction Spline: Decreases side-load and provides more uniform application of torque.
- System accuracy of the tool when used with a HYTORC power pack is +/- 3%.
- Using a calibrated gauge will enhance the accuracy of your HYTORC System.

The MXT+ Hydraulic Torque Tool has an extensive range of reaction arms available for various bolting assemblies and configurations. The image below shows the most common types of reaction arms which vary in both length and size. Please contact your local HYTORC representative for all available options.



LEGEND (CLOCKWISE FROM TOP LEFT)

- | | | |
|---------------------------|-------------------------------|--------------------------------|
| A. Crab Nut Fixtures | E. Rear Reaction Arm Assembly | I. HYTORC Nut Drive Assembly |
| B. WTCT Reaction Fixture | F. Offset Reaction Sleeve | J. HYTORC Washer Driver |
| C. Rotatable Reaction Arm | G. Reaction Sleeve | K. Reaction Arm Casted (Short) |
| D. ALCO Arm | H. Hex Drive | L. Track Pad Fixture |

3. PREPARATION AND SETUP

INSPECT TOOL

- Check the calibration sticker to verify the most recent calibration date.
- Inspect cycle counter to ensure lens is fully seated and not cracked.
- Monitor cycle count to aid in scheduling calibration and preventative maintenance.
- Remove and inspect the square drive and ensure there is no damage to the inner or outer splines.
- Inspect the uniswivel and couplers for signs of damage or oil leaks. Leaking tools should not be used.

DETERMINE REQUIRED DIRECTION OF ROTATION



For tightening, the square drive must be inserted so that "TIGHTEN" is visible when mounted on the application.



For loosening, the square drive must be inserted on the opposite side so that "LOOSEN" is visible when mounted.

CHANGING THE DIRECTION OF ROTATION

- Push button on drive retainer and pull the square drive to remove it from the tool.
- Remove the drive retainer and reinsert it on the opposite side of the tool.
- Insert square drive into opposite side of the tool while pushing button on the drive retainer.
- Release the button on the drive retainer after square drive clicks into place. Challenge drive to make sure it is secure.



Configuring Tool For Tightening



Configuring Tool For Loosening

4. BOLTING WITH SOCKET AND REACTION ARM

The tool is configured for conventional bolting by installing a socket and either a drive spline reaction arm or a rear spline reaction arm.

IMPORTANT: Do not place any part of your body between reaction arm and reaction point to avoid injury. Never modify a reaction arm! Changes in reaction arm may lead to personal injury or damage tool.


INSTALLING REACTION ARM (DRIVE SPLINE)

- Slide reaction arm over drive spline while aligning the Allen Set Screw with the flat on the Reaction Spline.
- Tighten Allen Set Screw to firmly attach the reaction arm to the spline.
- Challenge the reaction arm to make sure it is firmly secured onto the tool.



INSTALLING REACTION ARM (REAR SPLINE)

- Push the catch lever on the back of the reaction arm.
- Slide reaction arm over rear spline until seated.
- Release the catch lever.
- Challenge the reaction arm to make sure it is firmly secured onto the tool.
- Use rear spline cover to protect tool when not in use.



INSTALL SOCKET

NOTE: Make sure the rubber O-ring is installed on the socket before installation.


- Insert the retaining pin part-way into the socket as shown.
- Slide socket over square drive while aligning hole in the socket with hole in the square drive.
- Insert the retaining pin into the socket as shown.
- Push the pin through both socket and square drive until the pin is flush against the socket.
- Slide the O-ring over the pin to retain pin while operating the tool.



CONNECT HYDRAULIC HOSES

The tool and power pack are connected by a 10,000 PSI operating pressure (40,000 PSI burst) twin-line hose assembly. Each end of the hose has both a male and a female connector (the male coupler is inserted into the female). **NOTE:** An odd number of hoses is required to extend the hydraulic hose length.


- **IMPORTANT:** Make sure system is depressurized before connecting or disconnecting hoses.
- Make sure that all hydraulic hoses are rated for 10,000 PSI Operating Pressure.
- Remove protective caps from couplings and inspect couplings for dirt and debris.
- Connect supply hose to male coupling "A". Connect return hose to female coupling "R".
- To avoid tool malfunction, do not reverse coupler orientation.
- If daisy chaining hoses, use an odd number of hoses to preserve coupler orientation.
- Protect pump couplings with caps and plugs when not in use, to avoid damage and contamination.



QUICK-CONNECT COUPLERS (PUSH-PULL)

To connect hoses with quick-connect couplers, insert male end into female end and push until it snaps in place. Twist locking ring so that ball (A) does NOT align with slot (B) to prevent accidental uncoupling. To disconnect, align ball (A) with slot (B) and pull back locking sleeve.

IMPORTANT: Always make sure system is depressurized before disconnecting hoses.



INITIALIZE PUMP AND CHECK PRESSURE

NOTE: Always follow pump manufacturer's guidelines and instructions.

- Ensure that all components and connections are compatible and have sufficient power.
- Check that voltage and frequency of main supply outlet match information on the pump plate.
- Power-on pump and check that pressure builds to 10,000 psi in advance, 1,500 psi in retract.
- Air Powered Pump (optional): Verify air supply is 100 psi and 130 CFM.

DETERMINE PRESSURE REQUIREMENTS

- Tool Torque output is calibrated over a range of hydraulic pressures. Select pressure necessary for desired torque from the table provided.
- Adjust pump regulator to set the desired torque output. **NOTE:** Always adjust regulator pressure UP, not down.

SAMPLE TORQUE CHART

Pressure		Torque		
PSI	BAR	FT-LBS	KGM	Nm
1500	104	464	64	629
1600	110	496	69	672
1800	124	558	77	758
2000	138	622	86	843
2200	152	685	95	929
2400	165	748	104	1015
2600	179	812	112	1100
2800	193	875	121	1186
3000	207	938	130	1272
3200	220	1001	138	1357
3400	234	1064	147	1443
3600	248	1128	156	1529
3800	262	1191	165	1614
4000	276	1254	173	1700
4200	290	1317	182	1786
4400	303	1380	191	1871
4600	317	1444	200	1957
4800	331	1507	208	2043
5000	345	1570	217	2128
5200	358	1633	226	2214
5400	372	1696	235	2299
5600	386	1759	243	2385
5800	400	1822	252	2470
6000	414	1885	261	2555
6200	427	1948	269	2641
6400	441	2011	278	2726
6600	455	2074	287	2812
6800	468	2137	296	2897
7000	482	2200	304	2982
7200	496	2262	313	3067
7400	510	2324	321	3151
7600	524	2387	330	3235
7800	538	2449	339	3320
8000	552	2511	347	3404
8200	565	2572	356	3487
8400	579	2634	364	3570
8600	593	2695	373	3654
8800	607	2757	381	3737
9000	620	2818	390	3820
9200	634	2878	398	3901
9400	648	2938	406	3982
9600	662	2997	415	4063
9800	676	3057	423	4144
10000	690	3117	431	4225

1-800-FOR-HYTORC

HYTORC

HYTORC.COM


INSTALL HANDLE

- Installation and use of the tool handle ensures maximum safety when handling the tool.
- Simply thread the handle into the tool with the twist knob on top until firmly attached.
- Partially unscrew knob to rotate handle to desired position after the tool is mounted.



MOUNT TOOL ONTO THE APPLICATION

- Make sure tool is set up appropriately for TIGHTEN or LOOSEN with appropriate socket.
- Place the driver onto the socket, making sure socket is fully engaged.
- Position the reaction arm against an adjacent nut, flange or other solid reaction point.
IMPORTANT: Follow all safety instructions regarding reaction arms.
NOTE: If using rear-spline reaction arm, adjust arm as necessary to align with reaction surface.
- Make sure that hose connections are clear of obstructions and out of harm's way.
- If needed, install back wrench or apply back wrench fixture.
- THEN, AND ONLY THEN, apply momentary pressure to the system to ensure proper tool placement. If it doesn't look or act right, STOP and re-adjust the reaction arm.



Bolting With Drive Spline Reaction Arm



Bolting With Rear Spline Reaction Arm

CONVENTIONAL TORQUE TIGHTENING

- Press and hold the advance button on the pump control until you hear a click – the piston is fully extended, and the square drive will no longer turn.
- Release advance button to retract piston until you hear a click to signify tool is reset.
- Continue push-advance-click-release cycle until tool stalls and nut no longer visibly turns.
IMPORTANT: Always attempt one final cycle to ensure that “stall” point has been reached.

CONVENTIONAL TORQUE LOOSENING

- Set pump to the maximum pressure (10,000 PSI, 700 bar).
- Reverse the square drive and mount tool onto nut or bolt with “LOOSEN” visible.
- Repeat the same push-advance-click-release cycle outlined above until you can loosen the nut by hand.

RELEASING A LOCKED-ON TOOL


- The MXT+ Tool has an automated release feature and does not require manual release.
- Continue advancing the pump until the tool loosens and frees itself from the application. Remove tool.

5. BOLTING WITH THE HYTORC WASHER

The HYTORC Washer System consists of the HYTORC Reaction Washer and Backup Washer. The tool is configured for bolting with the HYTORC Washer by installing a dual-socket HYTORC Washer Driver. The driver engages the lobes of the washer while constraining the reaction force of the tool as it tightens.

NOTE: No reaction arm is required when bolting with the HYTORC Washer. Installation of the spline cover is recommended.

INSTALLING THE HYTORC WASHER DRIVER



- Slide the appropriate size HYTORC Washer Driver over the square drive and spline while aligning the thumb screw with the flat on the spline.
- Tighten the thumb screw to secure driver. Challenge the Driver to make sure it is secure.

TIGHTENING THE HYTORC WASHER

- Connect hydraulic hoses and set pump to desired torque output (refer to pages 11-12).
- Place the tool onto the nut and HYTORC Washer, so that the driver is fully engaged.
- Push and hold the advance button on the pump remote until the tool fully advances, then release.
- Continue successive cycles of "PUSH-ADVANCE-CLICK-RELEASE" until the tool "stalls" at the pre-set Torque/PSI and the nut no longer turns.

LOOSENING THE HYTORC WASHER

- Configure the HYTORC Washer Driver so that LOOSEN is visible when tool is mounted on the application.
- Turn up the pump pressure or torque value to the maximum or peak value.
- Mount the driver onto the application so that it engages both the nut and the HYTORC Washer.
- Apply pressure until the out sleeve moves freely.
- Loosen bolts gradually in reverse order of tightening, to prevent misalignment.
- Remove the nut and HYTORC Washer by hand.



HYTORC Washer




HYTORC Washer Driver

6. BOLTING WITH THE HYTORC NUT

The HYTORC Nut is a dual spline mechanical tensioning device that replaces regular hex nuts on an application. The tool is configured for bolting with the HYTORC Nut by installing the HYTORC Nut Driver. **NOTE:** No reaction arm is required when bolting with the HYTORC Nut. Installation of the rear spline cover is recommended.

INSTALLING THE HYTORC NUT DRIVER




- Push button on drive retainer and remove square drive.
- Slide the HYTORC Nut Direct Drive into the tool housing. Insert the special drive retainer on the opposite side and twist clockwise to tighten.
- Place the tool onto the HYTORC Nut, making sure that the driver is fully engaged.

TIGHTENING THE HYTORC NUT

- Connect hydraulic hoses and set pump to desired torque output (refer to pages 11-12).
- Push and hold the advance button on the pump remote until the tool fully advances, then release.
- Continue successive cycles of “PUSH-ADVANCE-CLICK-RELEASE” until the outer sleeve no longer turns and the tool stalls at the specified pressure.

LOOSENING THE HYTORC NUT

- Configure the HYTORC Nut Direct Drive so that LOOSEN is visible when tool is mounted on the application.
- Turn up the pump pressure or torque value to the maximum or peak value.
- Engage the Driver and the HYTORC Nut.
- Apply pressure until the out sleeve moves freely.
- Loosen gradually in reverse order of tightening, to prevent misalignment.
- Remove the HYTORC Nut by hand.



HYTORC Nut



HYTORC Nut Direct Drive

7. CARE AND MAINTENANCE

TOOL MAINTENANCE

- Maintenance must be performed by a qualified technician.
- Use rear spline cover to protect tool when not in use.
- Inspect the tool before each use. Repair or replace any obviously worn or damaged parts.
- Have the tool disassembled, cleaned, inspected and lubricated at least regularly. More frequent maintenance may be appropriate depending on local practice, usage and conditions.
- Modifying any of the components will invalidate the warranty.

CALIBRATION

- HYTORC recommends all tools be tested and recalibrated periodically. More frequent calibration may be appropriate depending on local practice, usage and conditions.
- Customer/user is responsible for arranging testing and recalibration.
- Contact 1-800-FOR-HYTORC for assistance or further information.
- When not in use store tool, components, instructions and calibration reports in plastic storage case.

April 2021 - First release.



HYTORC WORLD HEADQUARTERS

333 Route 17 North, Mahwah, NJ 07430 • +201-512-9500 • 800-FOR-HYTORC



THE HYTORC UNIVERSE IS MADE UP OF
OVER 1,000 TRAINED BOLTING SPECIALISTS
TO SUPPORT YOUR BOLTING NEEDS IN
OVER 100 COUNTRIES.

Locate your nearest HYTORC representative:

[HYTORC.COM/WORLD](https://www.hytorc.com/world)